
CALCULATE COLD START CONDITION
10
CALCULATE COLD-START COIL-PLUS-CONDUCTOR RESISTANCE
12
CALCULATE CONDUCTOR RESISTANCE
14
CALCULATE PRESENT COIL-PLUS-CONDUCTOR RESISTANCE
16
CALCULATE COIL RESISTANCE
18
CALCULATE COIL TEMPERATURE
20

Fig. 1